CLASSIC RIB[®] TABLE OF CONTENTS

Product

Page No.

Panel Information

Classic Rib Panel Profile	PCR-2
Panel Overview	PCR-2

Flashing Profiles

Eave (Direct Fasten)	PCR-3
Cleat	PCR-3
Box Gutter	
Box Gutter End	PCR-3
Universal Gutter/Downspout Strap	PCR-3
6" x 4" Downspout	PCR-3
6" x 4" 95° Elbow	PCR-3
Downspout Bracket	
Valley	PCR-3
Classic Rib Rake	
Rakewall	PCR-3
Pitch Break	PCR-3
Peak	PCR-3
11" Ridge/Hip Cover	PCR-3
20" Ridge/Hip Cover	PCR-3
Vented Ridge Cover	
Vent Drip	PCR-4
Classic Rib Inside Corner	PCR-4
Classic Rib Outside Corner	PCR-4
1.5" Sill/Head	PCR-4
1.5" Sill to Soffit	PCR-4
Head Jamb Cover	PCR-4
Classic Rib Jamb	PCR-4
1.25" Base	PCR-4

Accessory Profiles

Classic Rib Closures	PCR-5
Universal Closure	PCR-5
Classic Rib Light Transmitting Panel	PCR-5
Tube Sealant	PCR-5
Tape Sealant	PCR-5
Rubber Roof Jack	PCR-5
Retro Roof Jack	PCR-5
Rubber Roof Flashing Kit	PCR-5
Touch-Up Paint	PCR-5
Continuous Ridge Vent	PCR-5
Classic Rib Panel Shear	PCR-5
Vent Material	PCR-5
Louver with Screen	PCR-5

Testing Information

Section	Properties	and Gener	al Information	PCR-6
000000				


Design/Installation Considerations


Fastener Installation Technique	PCR-7
Condition of Substructure	
Fastening Information	PCR-8

Product	Page No.
Detail Conditions	
Eave Detail	PCR-9
Box Gutter Detail	PCR-9
Valley Detail	PCR-10
Rake Detail	
Rakewall Detail	PCR-11
Endwall Detail	PCR-11
High Side Eave Detail	PCR-12
20" Ridge/Hip Detail	
Ridge Detail	PCR-13
Gravel Stop Detail	PCR-13
Outside Corner Detail	PCR-14
Inside Corner Detail	
Jamb Detail	PCR-15
Head Detail	PCR-15
Base Detail	PCR-16

Notes


NotesPCR-16






TSmetal sales

© Metal Sales Manufacturing Corporation/ Subject to change without notice/ Effective Date 9/11 800.406.7387 (Corporate Office) • www.metalsales.us.com






metal sales

© Metal Sales Manufacturing Corporation/ Subject to change without notice/ Effective Date 9/11 800.406.7387 (Corporate Office) • www.metalsales.us.com

CLASSIC RIB[®] Section Properties and General Information




SECTION PROPERTIES				ALLOWABLE UNIFORM LOADS PSF (3 or More Equal Spans)															
	Width	Yield	Weight	Top in Co	npression	Bottom in C	ompression	Inward Load				Outward Load							
Ga.	Galini	PSF	lxx In⁴/ft	Sxx In³/ft	lxx In⁴/ft	Sxx In³/ft	1.5'	2'	2.5'	au 3'	3.5'	4'	1.5'	2'	2.5'	au 3'	3.5'	4'	
29	36"	80	0.62	0.0100	0.0151	0.0053	0.0118	142	81	52	36	27	21	179	103	66	46	34	26
26	36"	80	0.86	0.0123	0.0190	0.0080	0.0151	182	104	67	47	34	26	225	129	84	58	43	33

1. Theoretical section properties have been calculated per AISI 2001. "Specifications for the Design of Cold-formed Steel Structural Members." Ixx and Sxx are effective section properties for deflection and bending.

2. Allowable load is calculated in accordance with AISI 2001 specifications considering bending, shear, combined bending and sheer and deflection. Allowable load considers the worst case of 3 and 4 equal span conditions. Allowable load does not address web crippling or fasteners/support connection and panel weight is not considered.

- 3. Deflection consideration is limited by a maximum deflection ratio of L/180 of span.
- 4. Allowable loads do not include a 1/3 stress increase in uplift.
- 5. **Diaphragm Capacity -** 296 plf average Ultimate Shear Strength using the above fastening pattern on 2x supports located 2' on center per ASTM E 455-04




800.406.7387 (Corporate Office) • www.metalsales.us.com

FASTENER INSTALLATION TECHNIQUE

Recommended Tool Type - Use depth locating nose or adjustable clutch on screw gun to prevent overdrilling and strip out. **Do not use impact tools or runners.**

Seating the washer - Apply sufficient torque to seat the washer - do not overdrive the fastener.



To prevent wobbling - Make sure fastener head is completely engaged in the socket. If the head does not go all the way in the socket - tap the magnet deeper into the socket to allow full head engagement. Metal chips will build up from drilling and should be removed from time to time.

Protect drill point - Push only hard enough on the screw gun to engage clutch. This prevents excess friction and burn out of the drill point. Correct pressure will allow screw to drill and tap without binding.

Drilling through sheet and insulation - Ease up on pressure when drilling through insulation to avoid striking the purlin or girt with the point - apply more pressure after drill point contacts purlin or girt.

Drilling through purlin overlaps - Drilling through lapped purlins requires extra care. Excessive voids between purlins sometimes damages drill points and two self-drillers might be necessary to complete the operation. It is sometimes advantageous to predrill.


CONDITION OF SUBSTRUCTURE

Whether over solid substrate or open structural framing, panel distortion may occur if not applied over properly aligned and uniform substructure.


The installer should check the roof deck for squareness before installing Classic Rib panels. Several methods can be used to verify squareness of the structure for proper installation of the panels.

METHOD "A" - One method for checking the roof for squareness is to measure diagonally across one slope of the roof from similar points at the ridge and eave and obtain the same dimension.


METHOD "B" - The 3-4-5 triangle system may also be used. To use this system measure a point from the corner along the edge of the roof at a module of three (3). Measure a point from the same corner along another edge at a module of four (4). Then by measuring diagonally between the two points established, the dimension should be exactly a module of five (5) to have a square corner. Multiple uses of this system may be required to determine building squareness. If the endwall cannot be made square, the roof system cannot be installed as shown in these instructions.



CLASSIC RIB[®] Design / Installation Considerations (cont.)









metal sales


800.406.7387 (Corporate Office) • www.metalsales.us.com

CLASSIC RIB[®] VALLEY DETAIL








CLASSIC RIB[®] HIGH SIDE EAVE DETAIL











TTS metal sales

[©] Metal Sales Manufacturing Corporation/ Subject to change without notice/ Effective Date 9/11 800.406.7387 (Corporate Office) • www.metalsales.us.com